



Model 44/64/84/164 Supply Pressure Rating

NOTE: Required Supply Pressure = Discharge Pressure divided by amplification ratio of pump, see selection chart

NOTE: Add 10 PSI to Required Supply Pressure to allow for pressure differential of pump

